



.....3

.....3

.....4

.....4

.....5

.....5

.....6

.....7

PC ,USB PC  
 RS-485/RS-422 RS-485/RS-422 PC  
 USB RS-485/RS-422  
 RS-485/RS-422  
 USB/RS-485/422 USB  
 RS-422 RS-485 USB RS-422  
 RS-485  
 RS-422/RS-485 RS-422 RS-485  
 RJ-45 DB9 ,  
 I/O ( RTS DTR )  
 (RS-422) (RS-485) .

32 RS-422 RS-485 300-921600bps  
 USB  
 RS-422 USB RS-485

- 1 /
- 2 /
- 3 /
- 4 /

|     |          |          |                     |            |
|-----|----------|----------|---------------------|------------|
| USB |          | USB/DB-9 | /                   | ,          |
|     | RS-485   | RS-422   |                     |            |
|     | T/R+T/R- |          | A+/B- RXD+/RXD-     | A+/B-      |
| GND |          |          |                     | T/R+ T/R-, |
|     |          |          | T/R+ T/R- RXD+ RXD- |            |

1            USBV1.1   1.0   2.0

1 DB9 RS-485/RS-422



2 USB-C USB TYPE-C



▶ IISR至RS-485连接



RS-485设备



