

## UT-810N

### USB



2.

UT-810N

VER: 01

3.

USB RS-232

4.

1 USB UniversalSerial Bus Rev.1.1

2 RS-232

3 DB9

4 1Mbps

5

6

7 USB

8 +/-15KV ESD

9 (ASIC)USB

10 -25 70 , 5% 95%

11 Win98/Win2000/WinXP/Vista/Win7Win8/Linux

5.

RS-232C

DB9 Female(PIN)	RS-232C
1	
2	SIN (RXD)
3	SOUT (TXD)
4	DTR
5	GND
6	DSR



