

# UT-885

## USB

1.

UTEK  
Logo

2.

UT-885  
VER: 01

3.

USB RS-485/422

4.

1	USBV1.1	1.0	USB2.0,	RS-485	RS-422	TIA/EIA
2	USB	VCC DATA+ DATA-	GND FG			
3	RS-485	T/R+ T/R-	GND			
4	RS-422	T+ T- R+ R-	GND			
5			2	4		
6						
7		300-921600bps				
8			32	RS-422	RS-485	
9		RS-485/422	1200 (9600bps )	USB	5	
10		600W	± 15KV			
11		USB A	RS-485/422	5Pin		
12			PWR	TXD	RXD	
13						
14		62mm× 33mm× 16mm				
15		-40 85	5%	95%		
16		0-1.200	921600bps-300bps			
17		Windows95/98/2000/xp/Vista/Win7/8/8.1/10	IMAG			

4.1


FTDI FT232RL

5.

RS-485/RS-422

DB9 (PIN)		RS-422	RS-485
1	T/R+	(A+)	RS-485 (A+)
2	T/R-	(B-)	RS-485 (B-)
3	RXD+	(A+)	
4	RXD-	(B-)	
5	GND		

6.



7.

fl 7






10

	1PCS
	1PCS
	1PCS

11



12

-40 +85 , 5% 95%

13

# #

14

15